

Text center/Text fit/Reversing text

The text center command is an assist to placing a word or line of text in the middle of an area. Left click on the point you want to be center. Type height for text and a ratio value for height to length. Press enter. Type text and press enter.

```
Background File is loaded
End of MECH CONFIG S# 994904
Command:textctr Bottom Center: , Height<0.500>: , Ratio<0.750>:
```



The text fit command makes it possible to fit a word or line into a specific area.




In the above example, a border has been drawn. Now, we want to place a name inside the border using “textfit”.

```
Background File is loaded
End of MECH CONFIG S# 994904
Command:textfit, bottom left:
```

```
Background File is loaded
End of MECH CONFIG S# 994904
Command:textfit, bottom left: , top:
```

```
End of MECH CONFIG S# 994904
Command:textfit, bottom left: , top: , end:
text:
```



Select the bottom left, top left and end at top right. Type text and press enter.

Reversing Text – Occasionally you may want to engrave on clear acrylic plastic from the backside. The words need to be reversed for engraving so they read correctly from the uncut surface. Instead of selecting the bottom left, select the bottom right and continue to top and on to end, which is top left.

