

Zoom center/Zoom Window/Zoom Previous


The zoom center command allows you to see beyond the field of the mechanical limits you have set.



```
Command: zoomc, Zoom Center, Point:  
Height <5.338>: 10.00  
Command:
```


After clicking on the command you are asked to select a point. Place the cross-hair in the center of the screen and click. Enter a number larger than the one given for height. Press “ENTER”.

You can enter larger numbers like 20, 50, 100, to see larger areas outside your mechanical limits. Sometimes when you import a file from Autocad or Coral Draw, the drawing will be outside the mechanical limits.



Example of imported drawing that is outside the machine limits. The move command can drag the object into the limits.

The zoom window command allows you to select a specific area on the screen to zoom in on. Left click on a point at the edge of the area you want to magnify, and move the mouse across it. A red window frame will grow from the selected point. When-



the window surrounds the object, left click and the area will fill the screen.

The zoom previous command will take you back to the view you had before you created the current view. Repeated selection will move you back through several views.

